



AA402HSL Eyebolt anchor Installation Instructions



Things to know:

AA402 is designed for installation in concrete. It has been specifically developed for applications in rope access (abseiling) but it can be also used to support a fall arrest load of 15 kN provided a suitable personal shock absorber is used.

Fixing options:

M12 x 125mm HSL 3 or HSL-GR (HOLE 18 DIA)

Loading: Shear, not exceeding 20° with the surface it's installed in.

Tools needed for installation:

Rotary hammer drill, masonry drill bit 18, air pump, cleaning brush, torque wrench

Installation steps – M12 Hilti HSL-3 or HSL-GR in concrete:

1. Use Hilti Reo Scan or similar device to avoid drilling the steel reinforcement in concrete.
2. Mark the position for hole to be drilled.
3. Drill one M18 x 125mm hole. Ensure the hole is 90° with the drilled surface.
4. Clean the hole 3 times with compressed air and cleaning brush.
5. Install Hilti HSL-3 or HSL-GR and use a torque wrench to apply correct torque as per Hilti instructions.
6. Remove the M12 bolt inside the HSL-3 or HSL-GR and screw in AA402 instead

Proof load and certification:

All chemical and friction anchorages must be proof loaded before their initial use and subsequently on regular basis to satisfy the requirements set out in AS/NZS 1891.4:2009 and AS/NZS 4488.2:1997

- Proof load the eye to 7.5 kN for fall arrest applications
- Proof load the eye to 6 kN for applications in rope access

Note:

The roof structure must be assessed by a structural engineer unless it is clear to a suitably qualified person that it is capable of withstanding the forces imposed on it during arresting of a fall and during work positioning.

DISCLAIMER

All product specifications and technical descriptions, recommendations and other information provided in this document are given as general guidance and advice, and are to be considered in conjunction with Safety Roof Anchors installation instructions and any other data available and applicable to each particular standard product or system. Use of such data is however the user's sole responsibility taking into account the intended application and actual conditions existing on the specific worksite. Consequent selection of the right product for any particular use remains the user's ultimate responsibility.

Safety Roof Anchors is therefore not obligated or liable for any direct or indirect, incidental or consequential damages, losses or expenses in connection with, or by reason of the suitability and use of or otherwise, any product or system for any purpose. Implied warranties of merchantability or fitness for any particular purpose are specifically excluded. Safety Roof Anchors maintains a policy of continuous improvement and development, and therefore reserves the right to modify, amend or otherwise alter product and system designs and specification, models and part numbers, colours and pricing etc., without prior notice. Safety Roof Anchors accepts no liability whatsoever for incorrect information, errors or omissions.