



PG 1- Profile Grip anchor installation instructions



Things to know:

All Profile Grip anchor points can be used for rope access (abseiling) as well as to support a fall arrest load of 15 kN when a suitable personal shock absorber is used. Profile Grips can be used on all structurally sound roofs with either timber or steel underlying structure of the following minimum requirements:

Timber structure: Minimum size rafter/batten – 70mm x 35mm

Steel structure: Minimum purlin gauge – 150mm x 1.2mm

Roof sheet: Minimum sheet gauge – 0.42mm

Minimum roof size: There must be minimum of 3 purlins supporting the roof sheet

First purlin or batten: Never install Profile Grips into the first purlin or batten on the roof's edge!

Klip lok roof installation: Some Klip Lok designs can be surprisingly easy to unclip. The roof sheet must therefore be secured to the first purlin or batten directly above and below the installed Profile Grip.

Loading: Always load the Profile Grips in sheer under an angle not exceeding 30° with the surface of the roof.

Tools needed:

Cordless drill, 8mm drill bit, hex bit driver, rivet gun, brush and dust pan or vacuum

Installation steps:

1. Identify the roof profile using the set of SRA I.D. Keys and choose the correct Profile Grip for your roof.
2. Identify the host structure. Is it timber or metal? Set aside the right screws.
3. Locate purlin (or batten) and place the Profile Grip down onto the roof sheet. If installing into Custom Orb roof and some tray deck roofs you will need to remove one or two roofing screws to do so as the holes (1) must be positioned over the centre of the purlin or batten.

4. Install 2x 14G screws through the holes (1), through the roof sheet into the purlin or batten. Be sure you use the correct fixing screws for the steel or timber structure. Do not over tighten.
5. Drill 8 holes into the roof sheet through the pre-drilled holes (2) of the Profile Grip using 8mm drill bit.
6. Install eight aluminium bulbtite rivets provided using rivet gun.
7. Remove any steel shavings to prevent roof corrosion and install a weatherproof certification tag
8. The Profile Grip is now ready to be used.



Annual re-certification

All anchor points must be inspected and certified before their initial use and subsequently on regular basis to satisfy the requirements set out in AS/NZS 1891.4:2009 and AS/NZS 4488.2:1997

Note:

The roof structure must be assessed by a structural engineer unless it is clear to a suitably qualified person that it is capable of withstanding the forces imposed on it during arresting of a fall and during work positioning.

DISCLAIMER

All product specifications and technical descriptions, recommendations and other information provided in this document are given as general guidance and advice, and are to be considered in conjunction with Safety Roof Anchors installation instructions and any other data available and applicable to each particular standard product or system. Use of such data is however the user's sole responsibility taking into account the intended application and actual conditions existing on the specific worksite. Consequent selection of the right product for any particular use remains the user's ultimate responsibility.

Safety Roof Anchors is therefore not obligated or liable for any direct or indirect, incidental or consequential damages, losses or expenses in connection with, or by reason of the suitability and use of or otherwise, any product or system for any purpose. Implied warranties of merchantability or fitness for any particular purpose are specifically excluded. Safety Roof Anchors maintains a policy of continuous improvement and development, and therefore reserves the right to modify, amend or otherwise alter product and system designs and specification, models and part numbers, colours and pricing etc., without prior notice. Safety Roof Anchors accepts no liability whatsoever for incorrect information, errors or omissions.