

ROPE ACCESS PTY LTD T/AS SAFETY ROOF ANCHORS

www.safetyroofanchors.com.au

S.R.A. Fully Engineered Product Range | 400 Series | Allfits | Static Lines | Profile Grips | Ladder Restraint Brackets | Fixings




Reo Buster




AS EASY AS 1-2-3:


1. When rebar is encountered, while drilling with a hammer and a carbide hammer bit, immediately stop the hammer and remove the bit from the hole (failure to do this will severely damage a carbide hammer bit – regardless of manufacturer's claims).

2. With a rotary rebar cutter mounted in a drill motor with the selector in the rotary-only position. Insert the rotary rebar cutter into the hole and drill through the embedded rebar.





Remove the rotary rebar cutter after the rebar has been drilled completely through and finish drilling the hole with the hammer bit.



NOTICE:

The Relton carbide-tipped rotary rebar cutter is intended for rotary-only drilling; percussion (hammering action) will damage the tool. The rebar cutter is designed for use in a standard 1/2" chuck/drill-motor or SDS+ rotary hammer-motor with selector in rotary-only mode.